

# Start Guide

## NPM PULSERVO II EtherCAT Driver CiA402 PP Mode (1-axis) with 86EVA



**NPM**

顧客「満足」から「感動」へ。  
日本パルスモーター株式会社

86Duino Coding IDE 501

EtherCAT Library

(Version 1.1)

# Revision


Date	Version	Description
2024/12/31	Version1.0	New Release.
2025/1/23	Version1.1	Change Main-device to MDevice, and Sub-device or Slave to SubDevice

# Preface

In this guide, we will show you how to use the EtherCAT MDevice QEC-M-01 and the NPM Pulservo II (Closed-loop stepping motor Driver).

## Notes QEC’s PoE (Power over Ethernet)

In QEC product installations, users can easily distinguish between PoE and non-PoE: if the RJ45 house is red, it is PoE type, and if the RJ45 house is black, it is non-PoE type.



PoE (Power over Ethernet) is a function that delivers power over the network. QEC can be equipped with an optional PoE function to reduce cabling. In practice, PoE is selected based on system equipment, so please pay attention to the following points while evaluating and testing:

- 1. The PoE function of QEC is different and incompatible with EtherCAT P, and the PoE function of QEC is based on PoE Type B, and the pin functions are as follows:



- 2. When connecting PoE and non-PoE devices, make sure to disconnect Ethernet cables at pins 4, 5, 7, and 8 (e.g., when a PoE-supported QEC EtherCAT MDevice connects with a third-party EtherCAT SubDevice).
- 3. QEC’s PoE power supply is up to 24V/3A.

# 1. Connection and wiring hardware

The following devices are used here:


1. QEC-M-01(EtherCAT MDevice )
2. NPM Pulservo II (Closed-loop stepping motor Driver)
3. 24V power supply & EU-type terminal cable & LAN cable
4. PSM2-28 (Standard type Motor, frame size 28 mm square)



## 1.1 QEC-M-01


QEC EtherCAT MDevice.

1. Power Supply: Connect to Vs+/Vs- and Vp+/Vp- power supplies via EU terminals for 24V power.
2. EtherCAT Connection: Using the EtherCAT Out port (On the top side) connected to the EtherCAT In port of EtherCAT SubDevice via RJ45 cable.




## 1.2 NPM Pulservo II

**NPM Pulservo II**, a PLS2-EC series EtherCAT interface closed-loop stepping motor driver (NPM Step-Servo Driver). This figure shows an example of when the **PSM2-28** motor is connected.



1. EtherCAT Connectivity:
  - Two EtherCAT ports (CN7, CN8) for network communication.
  - EtherCAT ID setting switches (SW1, SW2) for device identification.
2. Signal Connections:
  - Input/output signal interface (CN1) for digital inputs and outputs.
  - Encoder connection (CN2) to track motor position.
  - Motor connection (CN3) for power and control.
3. Power Supply:
  - Main power input (CN4) for operating the motor.
  - Control power input (CN5) for driver control circuitry.
4. Safety and Status:
  - Torque-Off signal input (CN6) for emergency stop functionality.
  - LED indicators for driver status, EtherCAT status, and EtherCAT ID display.
5. USB Port:
  - USB interface (CN9) for configuration and monitoring.

## ID setting for Pulservo II Driver:



Change the EtherCAT ID (Configured Alias ID) value by configuring the rotary switch. The switch on the left shows 10 digits and the switch on the right shows 1 digit.

The setting range is 0 to 99.


**Note:** The ID Value (Configured Alias ID) set on the rotary switch is applied when the product is turned ON.

### ID Settings:

- The 7-segment LED indicates the Physical Address or EtherCAT ID (EtherCAT Configured Alias) value. The display value conditions are as follows:
- When all rotary switches are set to "0", the 7-segment LED indicates the EtherCAT Physical Address. Since there is no connection between the SubDevice (this product) and the MDevice, it indicates 0 (zero) until the Physical Address is assigned. When the MDevice assigns a physical address to each SubDevice (this product), its value is displayed.
- If the rotary switch is set to any other value other than "0", the 7-segment LED indicates the corresponding set value (EtherCAT Configured Alias).
- If the 7-segment LED of the ID is blinking, it indicates that the ID value is not set. It is set when the power is turned ON.

## 2. Software/Development Environment

Download 86duino IDE from <https://www.qec.tw/software/>.



The image shows the 86duino Coding IDE 501 download page. On the left, there is a logo and the title "86duino Coding IDE 501". Below the title, a paragraph describes the new major release, stating it is faster and more powerful, supporting a broader range of third-party EtherCAT sub-devices and introducing additional EthercatDevice classes, including a generic CiA 402 EtherCAT slave class. On the right, there is a blue sidebar with the text "Windows (ZIP file)", the date "Date: 2024.12.06", and a green "Download" button.

After downloading, please unzip the downloaded zip file, no additional software installation is required, just double-click 86duino.exe to start the IDE.



### Note:

If Windows displays a warning, click Details once and then click the Continue Run button once.

86duino Coding IDE 501+ looks like below.









### 3. Connect to PC and set up the environment

Follow the steps below to set up the environment:

1. Connect the QEC-M-01P to your PC via a Micro USB to USB cable (86Duino IDE installed).
2. Turn on the QEC power.
3. Open "Device Manager" (select in the menu after pressing Win+X) -> "Ports (COM & LPT)" in your PC and expand the ports; you should see that the "Prolific PL2303GC USB Serial COM Port (COMx)" is detected; if not, you will need to install the required drivers.  
(For Windows PL2303 driver, you can download [here](#))



4. Open the 86Duino IDE.
5. Select the correct board: In the IDE's menu, select Tools> Board > QEC-M-01 (or the QEC MDevice model you use).
6. Select Port: In the IDE's menu, select Tools > Port and select the USB port to connect to the QEC MDevice (in this case, COM9 (QEC)).



## 4. Use 86EVA with code

This example shows how to operate the EtherCAT MDevice (QEC-M-01) and the NPM Pulservo II (Closed-loop stepping motor Driver) through the 86Duino IDE's graphical low-code programming tool, 86EVA.


Software Tools Description:

- 86EVA (EVA, EtherCAT-Based Virtual Arduino):  
is a graphical EtherCAT configuration tool based on the EtherCAT Library in the 86Duino IDE and is one of the development kits for 86Duino.

This code establishes EtherCAT communication and controls the NPM Pulservo II driver in Profile Position (PP) mode. The motor's position is updated cyclically, and the target position alternates between 100,000 and 100,000 units, simulating continuous forward and reverse movements.

### Step 1: Turn on 86EVA and scan


The 86EVA tool can be opened via the following buttons.



Please select the correct COM port and then click the “Connect” button.



Once you have confirmed that the correct COM port has been selected of QEC-M-01, press the Connect button to start scanning the EtherCAT network.



The connected devices will be displayed after the EtherCAT network has been scanned.



## Step 2: Set the parameters

Press twice on the scanned device image to enter the corresponding parameter setting screen.


### QEC-M-01

Press twice on the image of the QEC-M-01 to see the parameter settings.



Please check the following configures.

1. Turn off the "Apply BIOS Settings".
2. Select "1ms" to the Cycle Time.



Click "Back" in the upper left corner to return.



## NPM Pulservo II


Press twice on the image of the NPM Pulservo II Driver to see the parameter settings.



The page will show the Object Name, Alias Address, Vendor ID, Product Code, Virtual Arduino Mapping, and Virtual Servo Configuration parameters.

Please change the Object Name to "motor".

It'll appear a keyboard after you click the Object Name.



Click "Back" in the upper left corner to return.






## Step 3: Generate the code

Once you've set your device's parameters, go back to the home screen and press the "Code Generation" button in the bottom right corner.




When you're done, double-click the OK button to turn off 86EVA, or it will close in 10 seconds.



The generated code and files are as follows:

- sketch\_sep10b: Main Project (.ino, depending on your project name)
- GPT.h: Parameters to provide to ChatGPT referred
- myeva.cpp: C++ program code of 86EVA
- myeva.h: Header file of 86EVA



**Additional note:** After 86EVA generates code, the following code will be automatically generated in the main program (.ino), and any of them missing will cause 86EVA not to work.

1. `#include "myeva.h"` : Include EVA Header file
2. `EVA.begin();` in `setup()` : Initialize the EVA function

## Step 4: Write the code

The programming code from 86EVA are set as the following by default:

- NPM Pulservo II: `EthercatDevice_CiA402` object.
- CiA402 mode: Profile Position (PP) mode.
- EtherCAT mode: `ECAT_SYNC`.
- Distributed Clock: Open. Follow the EtherCAT cycle time.

And here is the setting by users:

- EtherCAT Cycle time: 1 millisecond.
- Device Object Name: QEC-M-01 is "EcatMaster", and NPM Pulservo II is "motor".

This code establishes EtherCAT communication and controls the NPM Pulservo II driver in Profile Position (PP) mode. The motor's position is updated cyclically, and the target position alternates between 100,000 and 100,000 units, simulating continuous forward and reverse movements.

### A. In Setup Function:

In the `setup()` function initializes communication and configures the motor for CiA402 Profile Position (PP) mode. Follow the steps below:

1. Initialize Serial Communication
  - Start serial communication at a baud rate of 115200.
2. Start the 86EVA
  - Use the `EVA.begin()` function to start and initialize the EtherCAT network.
3. Set Profile Position (PP) Mode
  - Configure the motor to PP mode using `setCiA402Mode(CIA402_PP_MODE)`.
4. Enable the Motor
  - Use the `enable()` function to enable the motor and transition it to `CIA402_OPERATION_ENABLED`.
5. Configure Profile Parameters
  - Motion Profile Type: Linear Ramp, Profile Velocity: 100,000, Acceleration: 5,000, Deceleration: 5,000.

### B. In Loop Function:

In the `loop()` function, the current position of the motor is displayed on the Serial Monitor, and the motor alternates its movement back and forth in a repeating cycle:

1. State Machine Logic
  - case 0: Start the motor and move to the target position (100,000 units). Once the command is successfully executed, transition to the next state.
  - case 1: Wait for the motor to reach the target position. Once the target is reached, proceed to the next state.



- case 2: Start the motor and move back to the original position (-100,000 units). Once the command is successfully executed, transition to the next state.
- case 3: Wait for the motor to return to the original position. Once the target is reached, reset the state machine back to case 0 to repeat the movement cycle.

## 2. Code Logic Summary

- Use the `pp_Run()` function to initiate position movement.
- Use the `pp_IsTargetReached()` function to confirm whether the target position has been reached.
- The state machine starts at case 0 and resets after completing case 3.

The example code is as follows:

```
#include "myeva.h"

int pp_state = 0;



void setup() {
  Serial.begin(115200);
  while (!Serial);


  EVA.begin();
  motor.setCiA402Mode(CIA402_PP_MODE);
  Serial.print("Enable: "); Serial.println(motor.enable());
  motor.pp_SetMotionProfileType(0); // Linear ramp (trapezoidal profile)
  motor.pp_SetVelocity(100000);
  motor.pp_SetAcceleration(5000);
  motor.pp_SetDeceleration(5000);
}

void loop() {
  Serial.print("Pos: "); Serial.println(motor.getPositionActualValue());
  switch (pp_state)
  {
    case 0:
      if (motor.pp_Run(100000) == 0)
        pp_state++;
      break;
    case 1:
      if (motor.pp_IsTargetReached())
        pp_state++;
      break;
    case 2:
      if (motor.pp_Run(-100000) == 0)
```


```
    pp_state++;  
    break;  
case 3:  
    if (motor.pp_IsTargetReached())  
        pp_state = 0;  
    break;  
}  
}
```

**Note:**

Once the code is written, click on the toolbar to  compile, and to confirm that the compilation is complete and error-free, you can click  to upload.




After you successfully upload the program to the QEC-M-01, you can open the Serial Monitor on 86Duino IDE. Please check the Serial baud rate is same as your setting.



If the EtherCAT communication config successful, Serial Monitor will print "Enable: 0".



It will print the motor's current position to the serial monitor.



# Troubleshooting

## QEC-M-01 cannot successfully upload code

When you are unable to successfully upload code, please open 86EVA to check if your QEC EtherCAT MDevice's environment is abnormal. As shown in the figure below, please try updating your QEC EtherCAT MDevice's environment, which will include the following three items: Bootloader, EtherCAT firmware, and EtherCAT tool.



Now, we will further explain how to proceed with the update:


### Step 1: Setting up QEC-M

1. Download and install 86Duino IDE 500+ (or a newer version): You can download it from [Software](#).
2. Connect the QEC-M: Use a USB cable to connect the QEC-M to your computer.
3. Open 86Duino IDE: After the installation is complete, open the 86Duino IDE software.
4. Select Board: From the IDE menu, choose "Tools" > "Board" > "QEC-M-01" (or the specific model of QEC-M you are using).
5. Select Port: From the IDE menu, choose "Tools" > "Port" and select the USB port to which the QEC-M is connected.


## Step 2: Click “Burn Bootloader” button

After connecting to your QEC-M product, go to “Tools”> “Burn Bootloader”. The currently selected QEC-M name will appear. Clicking on it will start the update process, which will take approximately 5-20 minutes.

QEC-M-01:



## Step 3: Complete the Update



After completing the above steps, your QEC-M has been successfully updated to the latest version of the development environment.

# Warranty

This product is warranted to be in good working order for a period of one year from the date of purchase. Should this product fail to be in good working order at any time during this period, we will, at our option, replace or repair it at no additional charge except as set forth in the following terms. This warranty does not apply to products damaged by misuse, modifications, accident or disaster. Vendor assumes no liability for any damages, lost profits, lost savings or any other incidental or consequential damage resulting from the use, misuse of, originality to use this product. Vendor will not be liable for any claim made by any other related party. Return authorization must be obtained from the vendor before returned merchandise will be accepted. Authorization can be obtained by calling or faxing the vendor and requesting a Return Merchandise Authorization (RMA) number. Returned goods should always be accompanied by a clear problem description.

All Trademarks appearing in this manuscript are registered trademark of their respective owners. All Specifications are subject to change without notice.

©ICOP Technology Inc. 2024